

Calculation of the Stress intensity factor with CINT command in 2D
Workbench 13.0

Aalborg Universitet esbjerg
Søren Heide Lambertsen

File View Tools Units Help
New Open... Save Save As... Import... Reconnect Refresh Project Update Project Project Compact Mode

Toolbox

- Analysis Systems
 - Design Assessment
 - Electric
 - Explicit Dynamics
 - Fluid Flow (CFX)
 - Fluid Flow (FLUENT)
 - Harmonic Response
 - Hydrodynamic Diffraction
 - Hydrodynamic Time Response
 - Linear Buckling
 - Magnetostatic
 - Modal
 - Random Vibration
 - Response Spectrum
 - Rigid Dynamics
 - Shape Optimization
 - Static Structural
 - Steady-State Thermal
 - Thermal-Electric
 - Transient Structural
 - Transient Thermal
- Component Systems
- Custom Systems
- Design Exploration

Project Schematic

- A
 - 1 Static Structural
 - 2 Engineering Data ✓
 - 3 Geometry ?
 - 4 Model ?
 - 5 Setup ?
 - 6 Solution ?
 - 7 Results ?

Static Structural


Properties of Schematic A3: Geometry

	A	B
1	Property	Value
2	General	
3	Component ID	Geometry
4	Directory Name	SYS
5	Geometry Source	
6	Geometry File Name	
7	Basic Geometry Options	
8	Solid Bodies	<input checked="" type="checkbox"/>
9	Surface Bodies	<input checked="" type="checkbox"/>
10	Line Bodies	<input type="checkbox"/>
11	Parameters	<input checked="" type="checkbox"/>
12	Parameter Key	DS
13	Attributes	<input type="checkbox"/>
14	Named Selections	<input type="checkbox"/>
15	Material Properties	
16	Advanced Geometry Options	
17	Analysis Type	2D
18	Use Associativity	<input checked="" type="checkbox"/>
19	Import Coordinate Systems	<input type="checkbox"/>
20	Import Work Points	<input type="checkbox"/>
21	Reader Mode Saves Updated File	<input type="checkbox"/>
22	Import Using Instances	<input checked="" type="checkbox"/>
23	Smart CAD Update	<input type="checkbox"/>
24	Enclosure and Symmetry Processing	<input checked="" type="checkbox"/>
25	Mixed Import Resolution	None


Ready

Show Progress Show 6 Messages


Select Analysis type to 2D and then open the Design Modeler.



Create a crack in the geometry and close the Design modeler.




Open the model and refine the mesh. Radial/ring patterned mesh is not required.




In this example a edge mesh sizing is set to 0,5 mm and behavior to Hard.


Mesh
19-12-2011 11:01



The mesh.



Then set the boundary condition.



Select Named Selection.

File Edit View Units Tools Help | Solve | Worksheet

Show Vertices Wireframe Edge Coloring Thicken Annotations

Named Selection Named Selection

Outline

- Project
 - Model (A4)
 - Geometry
 - Coordinate Systems
 - Mesh
 - Edge Sizing
 - Named Selections
 - tip
 - Static Structural (A5)
 - Analysis Settings
 - Fixed Support
 - Pressure
 - Commands (APDL)
 - Solution (A6)
 - Solution Information

tip
19-12-2011 11:05

tip

0,000 2,500 5,000 7,500 10,000 (mm)

Geometry | Print Preview | Report Preview

Messages


Text	Association	Timestamp
Warni The default defeaturing tolerance was larger than one computed bas	Project>Model>Geometry>Surface Body Bo	12/19/2011 11:01:47 ,

Details of "tip"

Scope	
Scoping Method	Geometry Selection
Geometry	1 Vertex
Definition	
Send to Solver	Yes
Visible	Yes
Program Controlled Inflation	Exclude
Statistics	
Type	Manual
Total Selection	1 Vertex
Suppressed	0
Hidden	0

Press F1 for Help | 1 Message | No Selection | Metric (mm, kg, N, s, mV, mA) Degrees rad/s Celsius

Select the crack tip and rename the Selection.



Start a Command window and write the CINT commands.

Start a new calculation and name the calculation.

Cint,new,1

Enter the type of calculation. In this example the value of the j integral is calculated.

Cint,type,jint

Define the crack tip, in this example the crack tip is named tip

Cint,ctnc,tip

Enter the coordinate system here the x=1 y=2 z=3. In this example the coordinate is 0 with is the default coordinate system and 2 is the y axis with is normal to the crack direction.

Cint,normal,0,2

There are many other parameters there can be changed, in the example is command is the simplest setup possible. A extra command can be the contours number below the number is set to 10.

Cint,ncon,10

Start a new calculation and name the calculation.

Cint,new,1

Enter the type of calculation. In this example the value of the j integral is calculated.

Cint,type,jint

Define the crack tip, in this example the crack tip is named tip


Cint,ctnc,tip

Enter the coordinate system here the $x=1$ $y=2$ $z=3$. In this example the coordinate is 0 with is the default coordinate system and 2 is the y axis with is normal to the crack direction.

Cint,normal,0,2

There are many other parameters there can be changed, in the example is command is the simplest setup possible. A extra command can be the contours number below the number is set to 10.

Cint,ncon,10



Start a command window under solution and enter the command for printing the j integral solution.

To print the calculation number 1


Print,1,,JINT

Project

- Model (A4)
 - Geometry
 - Coordinate Systems
 - Global Coordinate System
 - Coordinate System
 - Mesh
 - Named Selections
 - Static Structural (A5)
 - Analysis Settings
 - Fixed Support
 - Pressure
 - Commands (APDL)
 - Solution (A6)
 - Solution Information
 - Commands (APDL)


Details of "Coordinate System"

Definition	
Type	Cartesian
Coordinate System ID	Manual
Coordinate System ID	12
Origin	
Define By	Geometry Selection
Geometry	Click to Change
Origin X	40, mm
Origin Y	50, mm
Principal Axis	
Axis	X
Define By	Global X Axis
Orientation About Principal Axis	
Axis	Y
Define By	Default
Directional Vectors	
Transformations	
Base Configuration	Absolute
Rotate Y	180, °
Rotate X	180, °
Transformed Configuration	[40, 50,]



Messages

Text	Association	Timestamp
Warn! The default defeaturing tolerance was larger than one computed bas	Project>Model>Geometry>Surface Body Box	12/19/2011 3:32:20 PI




Changes the direction of y axis.

Outline

- Project
 - Model (A4)
 - Geometry
 - Coordinate Systems
 - Global Coordinate System
 - Coordinate System
 - Mesh
 - Named Selections
 - Static Structural (A5)
 - Analysis Settings
 - Fixed Support
 - Pressure
 - Commands (APDL)
 - Solution (A6)
 - Solution Information
 - Commands (APDL)

Details of "Coordinate System"

Definition	
Type	Cartesian
Coordinate System ID	Manual
Coordinate System ID	12
Origin	
Define By	Geometry Selection
Geometry	Click to Change
Origin X	40, mm
Origin Y	50, mm
Principal Axis	
Axis	X
Define By	Global X Axis
Orientation About Principal Axis	
Axis	Y
Define By	Default
Directional Vectors	
Transformations	
Base Configuration	Absolute
Rotate Y	180, °
Rotate X	180, °
Transformed Configuration	[40, 50,]



Geometry | Print Preview | Report Preview

Messages

Text	Association	Timestamp
Warni	The default defeaturing tolerance was larger than one computed bas	Project>Model>Geometry>Surface Body Bo
		12/19/2011 3:32:20 P

Like this.


Calculation of the stress intensity factor. It is important that the coordinate system is correct, if the j-integral is negative switch the direction like in the example.

We add a new command. Changes to new,2


```
Cint,new,2  
Cint,type,sifs  
Cint,ctnc,tip  
Cint,ncon,10  
Cint,normal,0,2
```

And also print the result from calculation 2.


```
Prcint,2,,K1
```



Like this.



Like this.



$$K1 = 591 \text{ MPa} \cdot \sqrt{\text{mm}}$$

Calculated Stress intensity factor

$$K1 = 100MPa \cdot \sqrt{10mm \cdot \pi} = 560.5 MPa \cdot \sqrt{mm}$$

$$K1 = 100MPa \cdot \sqrt{10mm \cdot \pi} \cdot \frac{1 - \frac{a}{2w} + \frac{0.326a^2}{w^2}}{\sqrt{1 - \frac{a}{w}}} = 572.2 MPa \cdot \sqrt{mm}$$